

1/19




Fig. 1

2/19




Fig. 2

3/19




Fig. 3

4/19




Fig. 4

5/19




Fig. 5

6/19




Fig. 6

7 / 19




Fig. 7

8/19




Fig. 8



9/19




Fig. 9

10/19




Fig. 10

11/19




Fig. 11

12/19




Fig. 12

13/19




Fig. 13

14/19




Fig. 14

15/19




Fig. 15

16/19




Fig. 16



17/19




Fig. 17

18/19






Fig. 18


19/19



IN-WHEEL  
Fig. 19A



NEAR-WHEEL  
Fig. 19B



DIRECT DRIVE  
Fig. 19C